


Printer Diagnostic Page

Print on plain A4 at 100% / "Actual size". Turn OFF "Fit to page" and draft/economy mode.



1. Full-width bands Look for white lines, faded zones or one side lighter than the other.



2. Nozzle check Every little step should be there. Gaps mean blocked nozzles in that colour.



3. Alignment grid & colour registration Grid lines straight; the three crosses should sit exactly on top of each other.



4. Scale check This bar should measure exactly 10 cm. If not, "Fit to page" is on.



What your print is telling you

White lines across a band	Blocked inkjet nozzles. Head-clean once or twice. If gaps remain, the head may be failing.
Streak down every band	Laser: dirty laser window, low toner or a scratched drum. Inkjet: dirty print-head path.
Marks that repeat down the page	A drum or roller fault. Measure the gap with the ruler: the distance tells a technician which part.
Crosses don't line up	Colour registration is off. Run alignment/calibration, then reprint this page.
Corner marks uneven	The 5 mm marks in the corners should look equal. Uneven = paper skew: check the guides and pickup rollers.

Still not right after a cleaning cycle and fresh ink or toner?

We can check drivers, settings and the printer itself, and tell you honestly if it's worth fixing.

+44 7384 740784

pc-repair.services